



Ricoh Theta S 360-degree camera Tutorial

The Ricoh Theta S is a 360-degree camera that allows you to capture immersive photos and videos. Here's a basic guide on how to use it:

1. Power on the Camera:

- Press and hold the power button until the camera's indicator lights up. The camera will start up, and the indicator will turn blue.

2. Capture Photos:

- To take a 360-degree photo, press the shutter button (the big round button) on the front of the camera.
- You can also use the Theta mobile app (available for iOS and Android) to remotely control the camera and capture photos.

3. Capture Videos:

- To record a 360-degree video, switch the camera to video mode by pressing the mode button (next to the power button) until the video indicator lights up.
- Press the shutter button to start and stop recording.



4. Adjust Settings:

- You can change settings like exposure, ISO, and white balance through the mobile app or the camera's settings menu.
- Use the Theta app to configure settings and control the camera remotely via Wi-Fi.

5. Viewing and Sharing:

- To view your 360-degree photos and videos, transfer them to your computer or mobile device. You can also view them directly in the Theta app.
- The Theta S camera comes with software for stitching and editing your 360-degree content.
- To share your photos and videos, upload them to platforms like Facebook, YouTube, or websites that support 360-degree content.

6. Charging and Storage:

- The Theta S camera has internal storage, but it's a good idea to use a microSD card for additional storage.
- Charge the camera using the included USB cable and a USB power source. The battery is non-removable.

7. Camera app

The camera has a app for main SO like

Apple : <https://apps.apple.com/es/app/ricoh-theta/id1023254741>

Android: https://play.google.com/store/apps/details?id=com.theta360&hl=es_419&gl=US

In this app you can download the photos
conecting by wifi

